

3-in-1 Wood Cleaner Detergent

The Kärcher 3-in-1 wood cleaner has a powerful 3-in-1 formula which offers you an exceptional cleaning performance thanks to its active dirt remover, UV protective formula and extensive care. This wood cleaning detergent offers you an outstanding cleaning performance, care and protection in one simple step. This Kärcher wood cleaning detergent is suitable for use on all treated and un-treated wooden surfaces outside, including your decking.



Properties

- Powerful, intensive and gentle
- For cleaning all sensitive wooden surfaces
- Active dirt remover for quick and efficient cleaning of dirt and stains from emissions
- Efficient UV protection formula delays the darkening of wood
- Intensive care for all wooden surfaces such as decking, fences, houses etc.
- Suitable for all water-resistant wooden surfaces.
- The Plug 'n' Clean system is the easiest and quickest way to apply detergent using a Kärcher pressure washer
- Ready to use cleaning agent (RTU)

Application areas

- Wooden surfaces
- Wooden houses

Usage options

- High-pressure cleaners

Technical data

Container sizes	Packaging unit	Part number
1 l	6 Piece(s)	6.295-757.0
1 l	6 Piece(s)	6.295-883.0

Application

High-pressure cleaners

- Connect bottle to the pressure washer, put the suction hose in the bottle or pour the detergent into the tank. Dispense under low pressure, let it soak in for a short while and then rinse thoroughly under high pressure. Repeated application increases the care and protection effect.