OC 6-18 PREMIUM BATTERY SET

Battery-powered medium-pressure washer with Home & Garden app, 18 V exchangeable battery and battery charger, portable for intermediate cleaning without a power or water connection. The suction hose is available separately.



Made in Germany

18V

BATTERY INCLUDED

Order no.	1.328-522.0

- Pressure washer with integrated water tank (12 l), medium pressure (24 bar)
- 18 V battery platform, max. 12 min runtime, mobile water trolley
- 18 V battery, battery charger, flat jet nozzle, short and long spray lance

Technical data

EAN code		4066529128935
Battery powered device		1
Battery platform		18 V battery platform
Pressure	**bar**	max. 24
Pressure range		Medium pressure
Flow Rate	**l/h**	max. 200
Battery type		Lithium-ion exchangeable battery
Voltage	**V**	18
Capacity	**Ah**	2.5
Run time per battery charge	**min**	max. 12 (2.5 Ah)
Battery charging time with standard charger	**min**	300
Charging current	**A**	0.5
Voltage (power supply for battery charger)	**V**	100 – 240
Frequency (power supply for battery charger)	**Hz**	50 – 60
Colour		grey
Weight without accessories	**kg**	5.7
Weight incl. packaging	**kg**	8.6
Dimensions (L × W × H)	**mm**	349 × 321 × 586

Scope of supply

Versions: Battery and battery charger included
Battery: 18 V / 2.5 Ah Battery Power battery (1 pc.)
Charging accessories: 18 V Battery Power standard charger (1 pc.)
Flat jet nozzle
Integrated water filter
Adapter garden hose A3/4"
Wheels
Telescopic handle

Equipment

Water suction
Water tank volume: 12 l
Hose type: Medium-pressure flexible hose
Pressure trigger gun: Medium-pressure trigger gun
Spray lance: short and long







Self-sufficient and mobile cleaning

- The 12 litre water trolley allows independent cleaning on the go. The water is sufficient for 3 to 5 heavily soiled bicycles or several objects such as garden/camping chairs.
- The tank can be filled at any tap and is leak-proof thanks to the screw cap.
- Independent of the power supply thanks to battery technology (battery sold separately).

Practical accessory holder on the machine

- The hose, trigger gun and spray lance can be easily and safely stored on the device to save space.
- The accessory compartment at the back of the water trolley offers space for additional accessories.
- All accessories are always at hand, even when you're on the move.

Optimal mobility thanks to the wheels and ergonomic handle height .

- The aluminium telescopic handle can be extended for transport and retracted again for storage.
- Large wheels for safe and comfortable transport on rough terrain or garden paths.

OC 6-18 Premium Battery Set, 1.328-522.0, 2026-10-30

KÄRCHER

EQUIPMENT FOR OC 6-18 PREMIUM BATTERY SET
1.328-522.0


1–2


3–4


5


6


7


8


9


10


11


12


13


14

		Order no.	Description	
BATTERIES				
Battery Power 18/25	1	2.445-034.0	18 V / 2.5 Ah Kärcher Battery Power exchangeable battery with innovative Real Time Technology incl. LCD display to indicate battery level. Suitable for use in all devices on the 18 V Kärcher battery platform.	■
	2	2.445-100.0		■
Battery Power 18/50	3	2.445-035.0	18 V / 5.0 Ah Kärcher Battery Power exchangeable battery with innovative Real Time Technology incl. LCD display to indicate battery level. Suitable for use in all devices on the 18 V Kärcher	☐
	4	2.445-103.0		☐
Battery Power 18/80	5	2.445-106.0		☐
BATTERY CHARGERS				
Fast Charger Battery Power 18 V	6	2.445-036.0	The fast charger charges the 18 V/2.5 Ah Kärcher Battery Power exchangeable battery to 80% in just 44 minutes and can be used for all batteries on the 18 V Kärcher battery platform.	☐
HANDHELD				
Spray lance	7	2.644-173.0	For connecting Kärcher medium-pressure washers and accessories using the Quick Connect adapter. Compatible with all KHB and OC 6-18 models.	■
WT 12l water trolley	8	2.644-351.0	Featuring a water tank and portable base, the 12-litre water trolley is the perfect addition to the OC 6-18 battery-powered medium-pressure cleaner, which is available separately.	■
PS 20 Surface Cleaner	9	2.644-018.0	The power scrubber is the ideal accessory for the KHB- and OC 6-18 models when cleaning small areas and steps.	☐
WB 24 wash brush	10	2.644-136.0	The WB 24 wash brush for the KHB- and OC 6-18 models complements the integrated flat jet with the mechanical cleaning power of extra-long bristles.	☐
MJ 24 5-in-1 Multi Jet	11	2.644-171.0	Versatile 5-in-1 multi-jet spray lance for KHB and OC 6-18 models: the MJ 24 with spot, flat, rinsing, mist and stream jet. Easy to adjust simply by turning the nozzle head.	☐
VJ 24 360° variable spray lance	12	2.644-172.0	Variable spray lance with adjustable 360° joint: the VJ 24 for KHB and OC 6-18 models is ideal for cleaning hard-to-reach areas.	☐
DB 24 Rotary nozzle	13	2.644-472.0	The rotary nozzle for the KHB medium-pressure washer and OC 6-18 Outdoor Cleaner removes stubborn dirt powerfully and effectively. It is also ideal for cleaning narrow spaces.	☐
FJ 24 foam jet	14	2.644-135.0	The FJ 24 Handheld foam jet for dispensing Home & Garden detergents with KHB and OC 6-18 models.	☐

■ Included in delivery. ☐ Available accessories.

KÄRCHER

EQUIPMENT FOR OC 6-18 PREMIUM BATTERY SET
1.328-522.0


15


16


17–18


19


20


21


22


23


24


25


26


27

		Order no.	Description	
HANDHELD				
SH 5 suction hose	15	2.644-124.0	Flexible, 5-metre long suction hose for the KHB and OC 6-18 models for suctioning water from alternative sources such as water butts or water containers.	☐
VEHICLE MAINTENANCE				
Natural Car Shampoo	16	6.296-226.0	The 1L Natural Car Shampoo provides a 2-in-1 solution for exceptional cleaning performance. Suitable for all vehicles, it uses an ultra-shine and 98% nature-based formula.	○
Insect Remover	17	6.295-761.0	The Karcher insect remover gently removes insects from paint surfaces, radiator grilles, external mirrors, panels and plastic.	○
Insect remover 3in1, 500ml *Nordic	18	6.295-888.0	Gently removes insects from paint surfaces, radiator grilles, external mirrors, panels and plastic.	○
Natural Bike Cleaner	19	6.296-288.0	From handlebars to tyres, this Natual Bike cleaner is perfect for an all-round bike clean. The formula is gentle on materials yet effective at removing dirt.	○
Car Glass Cleaner	20	6.296-105.0	The Kärcher Car Glass Cleaner provides streak-free cleaning whilst reliably removing insects, fingerprints and dirt from your windows, mirrors, headlights and displays.	○
Interior Cleaner	21	6.296-106.0	The Kärcher Interior Cleaner is perfect for use in a wide variety of areas including dashboard and rubber seals, from upholstery and leather to door panels and floor mats.	○
Cockpit Care	22	6.296-107.0	Kärcher's Cockpit Care provides deep-cleaning care and protection for all your car's interior plastic and rubber surfaces.	○
Polish & Wax	23	6.296-108.0	Intensive cleaning and weather-resistant coating all in a single step. Fine scratches and streaks are removed, and the original colour brilliance is restored with the Kärcher Polish & Wax.	○
Rim Cleaner	24	6.296-048.0	With maximum cleaning power and quick-action formula this Karcher Rim Cleaner helps remove all kinds of dirt picked up by all common rim types while on the road.	○
Winter Screen Wash	25	6.296-109.0	The Kärcher Winter Screen Wash offers a reliable cleaning and frost protection agent for windscreens in temperatures to – 60° C whilst guaranteeing a streak and glare-free view.	○
Summer Screen Wash	26	6.296-110.0	A highly effective cleaning concentrate providing a clear, glare-free view all throughout summer. Effortlessly removing insect residue and bird droppings to be strong against summer dirt.	○
Bike Cleaner	27	6.295-763.0	Gently and effectively remove dirt such as brake dust, tyre wear, insects, mud and oil with the Kärcher bike cleaner. It's sticky gel formula makes it simple to use.	○

☐ Available accessories. ○ Detergent.