

WHEEL WASHING BRUSH

The Kärcher wheel washing brush is perfect for removing dirt and grime that accumulates on your wheel rims. With 360° degree cleaning enabling you to reach every angle of your wheels.



Order no. **2.643-234.0**

Technical data

EAN code		4039784920736
Colour		black
Weight	kg	0.3
Weight incl. packaging	kg	0.4
Dimensions (L × W × H)	mm	422 × 80 × 101

Uniform water distribution over 360°

- Cleans evenly and removes stubborn dirt.

High-quality brushes

- Efficient and gentle cleaning action

Detergent application

- Increased cleaning performance

COMPATIBLE MACHINES

- K 2 Classic
- K 2 Horizontal
- K 2 Start Plus
- K 2 Start Plus Car
- K 2 Start Plus Home
- K 3 Classic
- K 3 Classic Home
- K 3 Horizontal
- K 3 Power Control Car & Home
- K 3 eco!Booster
- K 3 eco!Booster Car & Home
- K 3 eco!Booster Home
- K 4 Classic
- K 4 Classic Home
- K 4 Power Control Flex
- K 4 Power Control Flex Car & Home Plus
- K 4 Power Control Go!Further
- K 4 Premium
- K 4 Silent eco!Booster
- K 4 WCM Flex eco!Booster
- K 4 WCM Flex eco!Booster Car & Home
- K 4 WCM Flex eco!Booster Car Plus
- K 4 WCM Flex eco!Booster Home
- K 5 Classic
- K 5 Classic Home
- K 5 Comfort Premium
- K 5 Comfort Premium Home
- K 5 Premium Power Control Flex
- K 5 WCM Flex eco!Booster
- K 5 WCM Flex eco!Booster Car & Home
- K 5 WCM Flex eco!Booster Home
- K 7 Comfort Premium
- K 7 WCM Flex eco!Booster

EQUIPMENT FOR WHEEL WASHING BRUSH
2.643-234.0



		Order no.	Description	
BRUSHES				
Adapter for garden hose connection	1	2.640-732.0		☐

☐ Available accessories.