WB 120 ROTATING WASH BRUSH

Rotating wash brush with interchangeable attachment for cleaning all smooth surfaces such as paint, glass or plastic. Quick and easy attachment changing thanks to the integrated release lever.



Order no.	2.644-060.0

Technical data		
EAN code		4054278476445
Colour		Black
Weight	kg	0.4
Weight incl. packaging	kg	0.5
Dimensions (L × W × H)	mm	309 × 153 × 135



Rotating brush head

- Gentle, soft and efficient cleaning.

Attachment change via release lever

- Quicker and easier attachment change without contact with dirt.

Detergent application via pressure washer

- Ideal dirt loosening and effective cleaning.

COMPATIBLE MACHINES

- K 2 Classic
- K 2 Horizontal
- K 2 Start Plus
- K 2 Start Plus Car
- K 2 Start Plus Home
- K 3 Classic
- K 3 Classic Home
- K 3 Horizontal
- K 3 Power Control Car & Home
- K 3 eco!Booster
- K 3 eco!Booster Car & Home
- K 3 eco!Booster Home
- K 4 Classic
- K 4 Classic Home
- K 4 Power Control Flex
- K 4 Power Control Go!Further
- K 4 WCM Flex eco!Booster
- K 4 WCM Flex eco!Booster Car & Home
- K 4 WCM Flex eco!Booster Car Plus
- K 4 WCM Flex eco!Booster Home
- K 5 Classic
- K 5 Classic Home
- K 5 Premium Power Control Flex
- K 5 WCM Flex eco!Booster
- K 5 WCM Flex eco!Booster Car & Home
- K 5 WCM Flex eco!Booster Home
- K 7 WCM Flex eco!Booster
- K Silent eco!Booster

WB 120 rotating wash brush, 2.644-060.0, 2026-11-13

EQUIPMENT FOR WB 120 ROTATING WASH BRUSH
2.644-060.0


1


2


3


4


5

		Order no.	Description	
BRUSHES				
Interchangeable attachment universal for WB 120 and WB 100	1	2.644-062.0	The wash brush interchangeable attachment Universal for the rotating wash brush is ideally suited to cleaning all smooth surfaces such as paint, glass or plastic.	☐
Interchangeable attachment car & bike for WB 120 and WB 100	2	2.644-063.0	Perfect for cleaning cars and motorbikes: The microfibre wash brush interchangeable attachment Car & Bike for the rotating wash brush.	☐
Interchangeable attachment home & garden for WB 120 and WB 100	3	2.644-064.0	For thorough cleaning of resistant surfaces around the home: The wash brush interchangeable attachment Home & Garden for the rotating wash brush.	☐
Garden hose adapter	4	2.640-732.0	Adapter for garden hose connection – suitable for attaching all Kärcher brushes to garden hoses with the quick-coupling system.	☐
MISCELLANEOUS				
Garden hose adapter FL	5	2.644-602.0		☐

☐ Available accessories.