SHOE!CLEANER SE 2, SE 3-18

Fast and drip-free shoe cleaning of sports footwear and casual shoes: the Shoe!Cleaner is the perfect accessory for the SE 2 and SE 3-18 Compact spot cleaners.



Order no.	2.863-369.0

Technical data		
EAN code		4066529107022
Colour		Black
Weight	kg	0.1
Weight incl. packaging	kg	0.1
Dimensions (L × W × H)	mm	115 × 59 × 42



Innovative Kärcher technology for optimum cleaning results

- Replaceable brush crown for thorough cleaning of soles and shoe uppers.
- Drip-free application because water is automatically vacuumed during the cleaning process.
- Low residual moisture for quick drying of textile surfaces.



Simple and convenient handling

- The system cleaning function prevents accessories from becoming dirty during cleaning applications. Hands stay clean and accessories can be stowed away immediately after use.
- Intuitive operation.



Soft bristles

- Dirt is removed from shoes thoroughly yet gently.
- Leaves no traces behind when cleaning delicate materials.

COMPATIBLE MACHINES

- SE 2 Spot Care Spot Cleaner