WASH BRUSH

Wash brush with soft bristles for cleaning sensitive areas and areas which are difficult to access in the outside area. Suitable for all Kärcher K 2 to K 7 pressure washers.



Order no.	6.903-276.0

Technical data		
EAN code		4002667004564
Colour		Black
Weight	kg	0.2
Weight incl. packaging	kg	0.2
Dimensions (L × W × H)	mm	333 × 82 × 164

Extra soft bristles

- Enables cleaning of sensitive areas

COMPATIBLE MACHINES

- K 2 Classic
- K 2 Horizontal
- K 2 Start Plus
- K 2 Start Plus Car
- K 2 Start Plus Home
- K 3 Classic
- K 3 Classic Home
- K 3 Horizontal
- K 3 Power Control Car & Home
- K 3 eco!Booster
- K 3 eco!Booster Car & Home
- K 3 eco!Booster Home
- K 4 Classic
- K 4 Classic Home
- K 4 Comfort Premium
- K 4 Power Control Flex
- K 4 Power Control Flex Car & Home
- K 4 Power Control Flex Car & Home Plus
- K 4 Power Control Go!Further
- K 4 WCM Flex eco!Booster
- K 4 WCM Flex eco!Booster Car & Home
- K 4 WCM Flex eco!Booster Car Plus
- K 4 WCM Flex eco!Booster Home
- K 5 Classic
- K 5 Classic Home
- K 5 Comfort Premium
- K 5 Comfort Premium Home
- K 5 Premium Power Control Flex
- K 5 WCM Flex eco!Booster
- K 5 WCM Flex eco!Booster Car & Home
- K 5 WCM Flex eco!Booster Home
- K 7 Comfort Premium
- K 7 WCM Flex eco!Booster
- K Silent eco!Booster
- K 3 Power Control Car & Home
- K 3 eco!Booster Car & Home
- K 2 Start Plus Car

Wash brush, 6.903-276.0, 2026-11-19

EQUIPMENT FOR WASH BRUSH
6.903-276.0


1


2

		Order no.	Description	
BRUSHES				
Garden hose adapter	1	2.640-732.0	Adapter for garden hose connection – suitable for attaching all Kärcher brushes to garden hoses with the quick-coupling system.	☐
MISCELLANEOUS				
Garden hose adapter FL	2	2.644-602.0		☐

☐ Available accessories.