

## COTTON MOP, 40 CM

Cotton mop, 40 cm, with pocket attachment, loops and outer fringes. Suitable for use with a Kärcher double bucket cart or single bucket cart with press.



Order no.

6.999-374.0

### Technical data

Programme		STANDARD
Type of flooring		Sealed Hard Floors (Parquet, Laminate, Vinyl, Stone) / Resilient floors
Floor structure		Smooth and lightly structured
Dirt level		Low to middle
Textile usage		Reusable textiles
Working width	cm	40
Textile attachment		Pockets
Material		70% cotton / 30% PET
Textile material		Cotton mix
Manufacturing type		PET-Woven carrier fabric with sewed-on loops
Textile structure		Loop pile
Washing temperature	°C	max. 90
Washing recommendation	°C	60
Dryer temperature	°C	60
Wash cycles <sup>9)</sup>		approx. 250
Quantity	Piece(s)	1
Weight per product / Weight per m <sup>2</sup>	kg	0.2
Package weight	kg	0.2
Dimensions (L × W)	mm	400 / 140
Dimensions, packaged	mm	400 × 140 × 10

### Application



#### Spray method

The cleaning water is applied to the floor directly in front of the mop, then the surface is wiped.



#### Preconditioned method

For optimum results, dampen the mop with cleaning water amounting to 250 % of its own dead weight.



#### Bucket method

For optimal moisture and a single-step wiping process, dip the mop fully into the cleaning water, allow it to absorb as much water as possible and then wring it out in the press.

### Properties

- Mop cloth with loops and fringe made of high-quality cotton
- With pockets
- Easy to wring out effectively
- Can be used with all conventional folding holders (40 cm)

<sup>9)</sup> Compliance with or use of recommended temperatures and detergents. In addition, the use of a dryer, especially at higher temperatures, may reduce the lifetime considerably.

We would be happy to advise you: Kärcher (U.K.) Ltd. \* Kärcher House \* Brookhill Way \* Banbury \* Oxon OX16 3ED

### Washing instructions

- Do not wash with other textiles
- Do not use bleach, softener or strongly alkaline detergents
- Washing or drying at high temperatures can damage the fibres
- Thoroughly rinse the textile before washing it

■ Please do not dry in the dryer