Wood cleaner RM 624

For the thorough cleaning of all treated and untreated water-resistant wooden surfaces such as garden furniture, wooden floors and decking. Very gentle on materials.



Made in Germany

Properties

- For cleaning all sensitive water-resistant wooden surfaces, can be used universally
- Dissolves oil/grease and mineral stains
- Removes algae, soot and mineral-based residues
- Cleaning using a Kärcher high-pressure washer
- Gentle on materials, suitable for glass, mirrors, and painted frames.
- pH value in concentrate approx. 9
- Ready to use cleaning agent (RTU)
- Can also be used manually
- Tailored to Kärcher devices with guaranteed material compatibility.
- Made in Germany

Application areas

Sealed wooden floors, parquet and laminate

Patio

Garden/terrace/balcony furniture

Usage options

- High-pressure cleaners
- Kärcher Spray Extraction Cleaners / Machines (SE series) & Manual Spot Treatment.

Technical data

Container sizes	Packaging unit	Part number
5 l	1 Piece(s)	6.295-361.0

Wood cleaner RM 624, 0.011-308.0, 2026-11-19

We would be happy to advise you: Kärcher (U.K.) Ltd. * Kärcher House * Brookhill Way * Banbury * Oxon OX16 3ED

Application

With pressure washer or manually

- Apply using your pressure washer or mix (1:10) in a bucket and apply using a sponge. Let it work in for a few minutes, then rinse well.

Wood cleaner RM 624, 0.011-308.0, 2026-11-19