Plastic cleaner RM 625

For the thorough cleaning of garden furniture, PVC window frames, children's slides and other plastic surfaces. Very gentle on materials.



Made in Germany

Properties

- Powerful, intensive and gentle
- Cleans, protects and maintains garden furniture, garden tools, plastic window frames and other plastic surfaces
- For cleaning all sensitive plastic surfaces, can be used universally
- Effectively dissolves oil, grease and mineral stains
- Can be used manually
- Ready to use cleaning agent (RTU)
- Cleaning using a Kärcher high-pressure washer
- Tailored to Kärcher devices with guaranteed material compatibility.
- Made in Germany

Application areas

For cleaning gardening machines and tools.

Garden/terrace/balcony furniture

Plastic

Usage options

- High-pressure cleaners
- Kärcher Spray Extraction Cleaners / Machines (SE series) & Manual Spot Treatment.

Technical data

Container sizes	Packaging unit	Part number
5 l	1 Piece(s)	6.295-358.0

We would be happy to advise you: Kärcher (U.K.) Ltd. * Kärcher House * Brookhill Way * Banbury * Oxon OX16 3ED

Application

With pressure washer or manually

- Apply using your pressure washer or mix (1:10) in a bucket and apply using a sponge. Let it work in for a few minutes, then rinse well.

Plastic cleaner RM 625, 0.011-309.0, 2026-11-19