# PS 30 POWER SCRUBBER SURFACE CLEANER

The PS 30 power scrubber, with its three integrated high-pressure nozzles, powerfully removes stubborn dirt from various surfaces, while saving time. Ideal for stairs and edges. Includes integrated squeegee blade to remove the dirty water.



| Order no. | 2.644-123.0 |
|---|---|

| Technical data | | |
|---|---|---|
| EAN code | | 4054278546858 |
| Colour | | Black |
| Weight | kg | 0.9 |
| Weight incl. packaging | kg | 1.2 |
| Dimensions (L × W × H) | mm | 744 × 293 × 769 |



### Three integrated high-pressure nozzles

- Powerful cleaning using high pressure for outstanding results.



### Integrated exchangeable squeegee blade

- Quick removal of dirty water with the replaceable squeegee blade.



### Brush head which can be rotated 360°

- Makes even hard-to-reach areas easy to access.

## COMPATIBLE MACHINES

- K 2 Classic
- K 2 Horizontal
- K 2 Start Plus
- K 2 Start Plus Car
- K 2 Start Plus Home
- K 3 Classic
- K 3 Classic Home
- K 3 Horizontal
- K 3 Power Control Car & Home
- K 3 eco!Booster
- K 3 eco!Booster Car & Home
- K 3 eco!Booster Home
- K 4 Classic
- K 4 Classic Home
- K 4 Comfort Premium
- K 4 Power Control Flex
- K 4 Power Control Flex Car & Home
- K 4 Power Control Flex Car & Home Plus
- K 4 Power Control Go!Further
- K 4 WCM Flex eco!Booster
- K 4 WCM Flex eco!Booster Car & Home
- K 4 WCM Flex eco!Booster Car Plus
- K 4 WCM Flex eco!Booster Home
- K 5 Classic
- K 5 Classic Home
- K 5 Comfort Premium
- K 5 Comfort Premium Home
- K 5 Premium Power Control Flex
- K 5 WCM Flex eco!Booster
- K 5 WCM Flex eco!Booster Car & Home
- K 5 WCM Flex eco!Booster Home
- K 7 Comfort Premium
- K 7 WCM Flex eco!Booster
- K Silent eco!Booster

PS 30 power scrubber surface cleaner, 2.644-123.0, 2026-11-19