PS 30 PLUS POWER SCRUBBER SURFACE CLEANER

The PS 30 Plus power scrubber removes stubborn dirt with its three high-pressure nozzles. Thanks to the swivelling side nozzle, all corners and edges are effortlessly cleaned.



Order no.	2.644-212.0

Technical data		
EAN code		4054278713311
Colour		Black
Weight	kg	0.9
Weight incl. packaging	kg	1.3
Dimensions (L × W × H)	mm	749 × 264 × 768



Swivelling side nozzle

- Perfect splash-free cleaning of all corners and edges.



Brush head which can be rotated 360°

- For full flexibility in hard-to-reach areas.



Bristle ring (also on the side nozzle)

- Protection against spray water, irrespective of nozzle setting.

COMPATIBLE MACHINES

- K 2 Classic
- K 2 Horizontal
- K 2 Start Plus
- K 2 Start Plus Car
- K 2 Start Plus Home
- K 3 Classic
- K 3 Classic Home
- K 3 Horizontal
- K 3 Power Control Car & Home
- K 3 eco!Booster
- K 3 eco!Booster Car & Home
- K 3 eco!Booster Home
- K 4 Classic
- K 4 Classic Home
- K 4 Comfort Premium
- K 4 Power Control Flex
- K 4 Power Control Flex Car & Home
- K 4 Power Control Flex Car & Home Plus
- K 4 Power Control Go!Further
- K 4 WCM Flex eco!Booster
- K 4 WCM Flex eco!Booster Car & Home
- K 4 WCM Flex eco!Booster Car Plus
- K 4 WCM Flex eco!Booster Home
- K 5 Classic
- K 5 Classic Home
- K 5 Comfort Premium
- K 5 Comfort Premium Home
- K 5 Premium Power Control Flex
- K 5 WCM Flex eco!Booster
- K 5 WCM Flex eco!Booster Car & Home
- K 5 WCM Flex eco!Booster Home
- K 7 Comfort Premium
- K 7 WCM Flex eco!Booster
- K Silent eco!Booster

PS 30 Plus power scrubber surface cleaner, 2.644-212.0, 2026-11-19