WB 130 ROTATING WASH BRUSH

Always in motion: The rotating wash brush with interchangeable attachment cleans smooth surfaces such as paint, glass or plastic. Quick attachment changes thanks to the integrated release lever.



Order no.	2.644-286.0

Technical data		
EAN code		4054278862682
Colour		Black
Weight	kg	0.4
Weight incl. packaging	kg	0.5
Dimensions (L × W × H)	mm	305 × 156 × 137

If you have any questions about the previous model, the WB 120, please contact one of our service partners or Kärcher retailers.

Rotating brush head

- Gentle, soft and efficient cleaning.
- Convenient and comfortable cleaning.

Attachment change via release lever

- Quicker and easier attachment change without contact with dirt.
- Always keep your hands clean.
- Choose the right attachment for different applications.

Detergent application with the brush connected to the pressure washer

- Ideal dirt loosening and effective cleaning.

COMPATIBLE MACHINES

- K 2 Classic
- K 2 Horizontal
- K 2 Start Plus
- K 2 Start Plus Car
- K 2 Start Plus Home
- K 3 Classic
- K 3 Classic Home
- K 3 Horizontal
- K 3 Power Control Car & Home
- K 3 eco!Booster
- K 3 eco!Booster Car & Home
- K 3 eco!Booster Home
- K 4 Classic
- K 4 Classic Home
- K 4 Comfort Premium
- K 4 Power Control Flex
- K 4 Power Control Go!Further
- K 4 WCM Flex eco!Booster
- K 4 WCM Flex eco!Booster Car & Home
- K 4 WCM Flex eco!Booster Car Plus
- K 4 WCM Flex eco!Booster Home
- K 5 Classic
- K 5 Classic Home
- K 5 Comfort Premium
- K 5 Comfort Premium Home
- K 5 Premium Power Control Flex
- K 5 WCM Flex eco!Booster
- K 5 WCM Flex eco!Booster Car & Home
- K 5 WCM Flex eco!Booster Home
- K 7 Comfort Premium
- K 7 WCM Flex eco!Booster
- K Silent eco!Booster
- K 5 WCM Flex eco!Booster Car & Home
- K 4 WCM Flex eco!Booster Car & Home
- K 4 WCM Flex eco!Booster Car Plus
- K 4 Power Control Flex Car & Home
- K 4 Power Control Flex Car & Home Plus

WB 130 rotating wash brush, 2.644-286.0, 2026-11-19

EQUIPMENT FOR WB 130 ROTATING WASH BRUSH
2.644-286.0


1


2


3


4


5

		Order no.	Description	
BRUSHES				
Interchangeable attachment universal for WB 130	1	2.644-289.0	Ideal for cleaning all smooth surfaces such as paint, glass or plastic: The interchangeable Universal attachment for the WB 130 rotating wash brush.	☐
Interchangeable attachment car & bike for WB 130	2	2.644-290.0	Perfect cleaning of cars and motorbikes: The interchangeable Car & Bike microfibre attachment for the WB 130 rotating wash brush.	☐
Interchangeable attachment home & garden for WB 130	3	2.644-291.0	For thorough cleaning of resistant surfaces around the home: The interchangeable Home & Garden attachment for the WB 130 rotating wash brush.	☐
Garden hose adapter	4	2.640-732.0	Adapter for garden hose connection – suitable for attaching all Kärcher brushes to garden hoses with the quick-coupling system.	☐
MISCELLANEOUS				
Garden hose adapter FL	5	2.644-602.0		☐

☐ Available accessories.