HOUSEHOLD KIT

Handy accessory kit for switching between dry floor nozzle and upholstery nozzle. Suitable for all Kärcher Home & Garden wet and dry vacuum cleaners and spray extraction cleaners.



Order no.	2.863-356.0

Technical data		
EAN code		4066529058003
Quantity	-part	3
Standard nominal width	mm	ID 35
Colour		Black
Weight	kg	0.4
Weight incl. packaging	kg	0.5
Dimensions (L × W × H)	mm	260 × 65 × 257

Switchable dry floor nozzle

- It has an ergonomic foot switch to quickly and easily adjust the floor nozzle for different floor coverings (e.g. carpet or laminate/parquet).
- The symbols for carpet and hard floor, familiar from dry vacuum cleaners, make it very easy to select the right setting.

Including parking clip (can only be used for WD vacuum cleaners)

- Can be attached to the floor nozzle if desired.
- Designed for quick and easy intermediate parking of suction tube and nozzle during working interruptions.

Upholstery nozzle with two thread lifters

- For gentle and thorough cleaning of upholstery, upholstered furniture and textile surfaces.

COMPATIBLE MACHINES

- SE 4 Select Carpet Cleaner
- WD 2 Plus S V-15/4/18/C
- WD 2 Plus V-12/4/18/C
- WD 2 Plus V-15/4/18/C
- WD 3 P V-17/6/20
- WD 3 V-17/4/20
- WD 4 V-20/5/22
- WD 5 V-25/5/22
- WD 6 P S V-30/8/22/T

Household kit, 2.863-356.0, 2026-11-19