

VehiclePro Klear!Rim Foam RM 802

Alkaline rim cleaner, highly concentrated, high foam and particularly gentle on materials. Extreme cleaning power for very dirty light alloy and steel rims.

pH value 13
in concentrate



Properties

- Highly effective rim cleaner
- Reliably removes brake dust, tyre wear, winter salt residues and limescale stains
- Gentle on materials
- Does not attack uncoated concrete floors and steel drive-up ramps
- Tensides biodegradable in accordance with EEC 648/2004
- More than 90% biodegradable
- NTA free
- Highly concentrated
- VDA-compliant

Usage options

- Self-service washing stations
- Car washes

Application areas

Car dealership and garage	Wheel rim cleaning
Haulage contractors, bus operators	Wheel rim cleaning
Service stations, oil companies	Wheel rim cleaning
Self-service washing stations	Wheel rim cleaning

Technical data

Container sizes	Packaging unit	Part number
20 l	1 Piece(s)	6.295-934.0

Application

Car washes

- Insert the product into the system.
- Start washing programme.

Self-service washing stations with MultiApp lance

- Set the dosage and temperature on the device
- 1-40°C processing temperature.
- Apply foam using the MultiApp lance from bottom to top.
- Allow to soak.
- Reaction time 1 min.
- Clean the surface with a high-pressure wash.

Self-service washing station with Power foam lance

- Set the dosage and temperature on the device
- 1-40°C processing temperature.
- Clean the object with foam from the bottom to the top with the Power foam lance.
- Allow to soak.
- Reaction time 1 min.
- Clean the surface with a high-pressure wash.



Instructions for use

- Do not let the cleaning solution dry out.
- Do not spray onto hot surfaces.
- Do not apply to unpainted or damaged light metal surfaces.
- For special rims, see manufacturer's instructions.
- Store away from frost.

Warnings and safety recommendations according to EC Directives

- Danger
- H290 May be corrosive to metals
- H314 Causes severe skin burns and eye damage
- P280 Wear protective gloves/protective clothing/eye protection/face protection.
- P305 + P351 + P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- P310 Immediately call a POISON CENTER/doctor.
- P303 + P361 + P353 IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water [or shower].
- P405 Store locked up.
- P501a Dispose of contents/container in accordance with local/regional/national/international regulations.

Dosage and yield

Contents	Cleaning method	Dosage	Soiling	Productivity
1000 ml	Self-service washing stations with MultiApp lance	2 - 3 %	strong	500 Rims
1000 ml	Vehicle wash system	2 - 3 %	strong	500 Rims
1000 ml	Self-service washing station with Power foam lance	1 %	strong	500 Rims